

What to do if you can't hear each other in bluetooth helmets

Step 1: Increase volume. Remove helmets and press the plus button to increase volume. Test the helmets to see if this resolves the issue.

Step 2: Reboot the helmets. Tap the plus button and center button at the same time to turn the helmets off, then **press and hold** the plus and center button at the same time to turn the helmets back on. Once the helmets are on, **tap** the center button once to turn on Mesh intercom. You should hear the helmet say "Mesh Intercom On, Channel X."

Basic Operations

Powering On



Powering Off



Volume Up



Volume Down



Mesh Intercom™

Mesh Intercom: communication within the same channel.

- For more information on **Mesh Intercom**, refer to the User's Guide.

Mesh Intercom On



Mesh Intercom Off

